



MADE IN U.S.A.

# YAZOO

## Parts Manual for


### S22CB1 SERIES 22" BIG WHEEL MOWER



Professional Quality Lawn Care Equipment  
since 1945

**Yazoo Manufacturing Company's** policy is to improve its products whenever it is possible and practical to do so. In an effort to keep pace with changes in technology, Yazoo reserves the right to make changes or improvements at any time without incurring any obligation to make such changes on products previously manufactured.


## HANDLE ASSEMBLY



## HANDLE ASSEMBLY

ITEM	PART NO.	DESCRIPTION
1	0703-023	Grip, 5/16"
2	1201-114	Bail, Engine
3	1201-113	Bail, Clutch
4	0204-168	Bushing, 5/16 Nylon (2)
5	0301-158	Control, Throttle
6	0401-394	Decal, Traction
7	0209-045	HHCS, 1/4"Cx1-3/4G5
8	0301-160	Cable, Clutch
9	1401-009	Nut, 1/4" Lock (2)
10	0309-020	Clamp, Cable (3)
11	0401-395	Decal, Engine Kill
12	0214-515	Mount, Engine Cable
13	0209-032	HHCS, 1/4Cx1-1/4G5
14	1104-020	Knob, 5/16C (2)
15	0401-399	Decal, Stablize Machine
16	0209-835	CVHB, 5/16Cx2 (2)
17	0801-024	Handle, Lower
18	0801-025	Handle, Upper
19	0209-084	HWST, 5/16Cx5/8 (2)
20	0209-080	HWST, 5/16Cx3/4 (2)
21	0301-159	Cable, Engine
22	0703-013	Grip, Handle

## MOWER DECK ASSEMBLY




## MOWER DECK ASSEMBLY

ITEM	PART NO.	DESCRIPTION
1	0401-407	Decal, Vari-Mulch (Commercial)
2	0401-398	Decal, Cutting Height
3	0804-093	Hood (Includes Decals)
4	0209-085	HWST, 1/4Cx1/2 (4)
5	0214-512	Rail, LH
6	0209-084	HWST, 5/16Cx5/8 (12)
7	1608-167	Pulley, Spindle
8	0205-059	Belt, Deck / Spindle
9	1401-069	Nut, 5/8F Jam (1)
10	0213-053	Brace, Spindle
11	0703-012	Grip, 3/8
12	1808-318	Rod, Mulcher Control
13	0214-511	Rail, RH
14	1916-140	Spring
15	0209-080	HWST, 5/16Cx3/4 (3)
16	1303-031	Hinge, Mulcher
17	1808-316	Pivot, Mulcher
18	1401-129	Pushnut, 3/8"
19	1401-020	Nut, 5/16 Hex (4)
20	2301-004	Washer, 5/16 Lock (4)
21	0209-108	HHCS, 5/16Cx3/4G5 (4)
* 22	0806-233	Housing, Spindle Weldment
23	0204-019	Bearing, Spindle (2)
* 24	1904-294	Shaft, Spindle
* 25	0806-341	Housing, Spindle Asm.
26	1806-148	Ring, Tolerance
27	0206-950	Blade, 22" Mulch
28	2301-096	Washer, Bevel
29	1303-029	Plate, Mulcher
30	2301-024	Washer, Flat .50 I.D.
31	0209-083	Bolt, Shoulder (2)
32	2302-010	Wheel, 8x1.75 (2)
33	0209-082	Bolt, Shoulder (2)
34	2301-016	Washer, 1/2" Bevel (6)
35	0214-510	Adjuster, Height RH
36	0214-513	Mount, Wheel RH
37	1401-132	Nut, 3/8C Nyloc (2)
38	0214-514	Mount, Wheel LH
39	0214-509	Adjuster, Height LH
40	0402-011	Deck, 22" Mower
41	0401-118	Decal, USA
42	0401-111	Decal, Cut Finger (2)
43	1401-070	Nut, 5/8F Cerlock Half
44	0101-163	Adapter, Blade
45	0609-015	Flap, Drag
46	1401-133	Nut, 1/4C Hex Nyloc (3)
47	0307-050	Clip, Drag Flap (3)
48	0209-021	HHCS, 1/4C x 3/4 G5 (3)
49	0314-034	Shield, Dust
50	1808-314	Link, Front Lift (2)
51	0902-005	Indicator, Cut
52	1102-013	Key, 3/16 Woodruff (2)
53	0705-056	Guide, Belt

} Replaced by KIT

~~1107-027~~

## DRIVE & HEIGHT ADJUSTMENT ASSEMBLY



## DRIVE &amp; HEIGHT ADJUSTMENT

## ASSEMBLY

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	0402-012	Deck, Rear	39	1901-233	Screw, Lift
2	0401-396	Decal, Mulch	40	0502-023	Swivel, Height
3	1913-101	Spacer, Lift Screw	41	1401-130	Nut, 1/4C TLF
4	0215-184	Bushing, 1/2" Machinery	42	0605-900-101	Weldment, Lift
5	1104-019	Knob, Lift	43	0204-084	Bushing, 5/8 Nylon (4)
6	1604-014	Pin, Roll 3/16 x 1-1/4 (2)	44	1913-102	Spacer, Axle (2)
7	0209-341	HHCS 3/8Fx2 GR5	45	1904-292	Shaft, Axle
8	0209-084	HWST, 5/16C x 5/8 (12)	46	1917-057	Sprocket, 48T
9	0704-017	Guard, Chain	47	1102-013	Key, 3/16 Woodruff
10	1915-186	Spring, Clutch	48	1901-005	SHSS, 1/4C x 1/4 (2)
11	0214-516	Mount, Clutch Stop	49	0305-027	Chain (54Pt)
12	1604-167	Pin, Clutch Stop	50	1808-315	Link, Front Lift (2)
13	0309-063	Clip, 3/8 Pin (3)	51	1808-314	Link, Rear Lift (2)
14	0310-007	Clutch	52	0502-022	Swivel, 3/8 (2)
15	0204-087	Bushing, Bronze	53	0401-220	Decal, OPEI-90
16	E270	Engine, 5 h.p. B&S I/C	54	1608-168	Pulley, Engine
17	1604-168	Pin, Whl Driver 1/4 x 1-1/2 (6)	55	1401-032	Nut, Hex 3/8F
18	1915-049	Spring, Ratchet (6)	56	2301-006	Washer, 3/8 Lock
19	2302-008	Wheel, Traction Asm. (2)	57	0209-318	HHCS, 3/8F x 1 G5
	2005-006	Tube, Traction (2) (Not Shown)	58	1608-170	Pulley, Idler
	2003-006	Tire, Traction (2) (Not Shown)	59	0301-152	Cable, Clutch
20	1913-095	Washer, 5/8 Flat (2)	60	2301-054	Washer
21	1806-149	E-Ring, 5/8 (2)	61	0214-507	Mount, Rear Wheel LH
22	1803-016	Ratchet, RH	62	1803-017	Ratchet, LH
23	1604-165	Pin, Roll 3/16 x 1-1/4 HD (2)	63	1102-020	Key, 3/16 Sq. x 3/4
24	0209-082	Bolt, Shoulder (2)	64	1913-300	Spacer, Sprocket
25	2301-055	Washer, 1/2 Conical (2)	65	1401-020	Nut, 5/16C Hex (3)
26	0214-508	Mount, Rear Wheel RH	66	2301-004	Washer, 5/16 Lock (3)
27	1401-129	Pushnut, 3/8 (6)	67	2301-022	Washer, 3/8 Flat
28	1913-099	Spacer, Wheel (2)	68	1401-032	Nut, 3/8 Nyloc
29	0214-506	Brkt., Axle Mounting LH	69	1913-305	Spacer, Idler Pivot
30	0214-534	Brkt., Axle Mounting RH	70	0102-155	Arm, Idler w/bushing
31	1921-012	Support, Clutch	71	0215-178	Bushing, Bronze
32	0209-120	HHCS, 5/16C x 1-1/4 G5 (2)	72	0209-337	HHCS, 3/8Cx1-3/4 Gr5
33	1401-231	Nut, Tinnerman	73	0214-536	Brkt., Spring Mount
34	0209-100	HHCS, 5/16C x 5/8 G5 (4)	74	1916-055	Spring, Idler
35	1605-126	Plate, Tie (2)	75	1401-232	Nut, 5/16C HSWH (2)
36	1401-021	Nut, 5/16C Lock (4)	76	0209-080	HWST, 5/16Cx3/4 (2)
37	0209-150	HHCS, 5/16C x 2-1/2 G5	77	0303-088	Cap, Hub (2)
38	0214-517	Mount, Spring	78	1401-030	Nut, 3/8C Hex

optional parts for loose chain

- 1 - 1808-345 Adjustable Rod - Replaces # 51
- 1 - 0502-022 Nut
- 1 - 1401-129 cap
- 1 - 0309-063 clip